



Build the project

Open the MainForm by double clicking



Add an OPCComm from the ToolBox

Set the OPCServer property and OPCTopic if necessary



Add a DigitalPanelMeter from the Toolbox

Set the PLCAddressValue Property