

INSTRUCTIONS

SPACER INSTALLATION

1. Remove two caliper assembly nuts, and remove anvil half of caliper.
2. Slide spacer over caliper assembly bolts.
3. Reassemble anvil on bolts and install two nuts removed in step 1.
4. Torque nuts as follows:
 - 150 calipers — 20 to 22 ft.-lbs.
 - 175 calipers — 31 to 35 ft.-lbs.
5. Prior to use, test caliper to verify function.

AIRHEART[®] BRAKE DIV., TOL-O-MATIC, INC., Hamel, MN 55340
3999-0073_01 URL: <http://www.tolomatic.com>